



NORAMCO *Fitness*



13901 Highway 105 West
Conroe, Texas 77304
800.827.2017

www.NoramcoFitness.com

Super Tread Treadmills Display Board Version Test

This procedure will determine which display board version has been installed in the Noramco Fitness Treadmill. Before attempting to recalibrate the display board, use the following procedure to determine which display version is installed in the treadmill.

- With the treadmill plugged in and idle, remove the emergency stop magnet and replace it while watching the “Speed” window in the lower left part of the display.
- If the “Speed” window lights up with a number - .4, .5, .6 or .7 – the display is a version 1.4, 1.5, 1.6 or 1.7 respectively. The calibration instructions are the same for any 1.x board version.
- If there is no number in the “Speed” window when the magnet is placed on the display, look at the “Time” window at an angle from below. There will be two LEDs lit behind and slightly above the “Time” window. This indicates a version 2 display.
- Version 3.0 displays will light up with the series number – “4600” – in the “Time” window, and the program level – “C”, “CC”, “PR”, “PRC”, or “HRT” – in the “Calorie” window.